

MODEL 202010X92A

REPAIR PARTS


KEY NO.	DESCRIPTION	PART NO.
1	Engine ‡	-----
2	Housing	7501015
3	Height Adjuster, Left Rear	1101565
4	Knob	071495
5	Wheel and Tire (White)	020270
6	Locknut, Flange	015x84
7	Bolt, Carriage	002x81
9	Bolt, Engine	0025x6
10	Nut	015x68
11	Height Adjuster, Left Front	1101563
12	Washer, Belleville	17x137
13	Washer	17x124
14	Bolt, Hex	01x142
15	Blade, Side Discharge	042785E701
16	Adapter, Blade	071056
17	Height Adjuster, Right Front	1101562
18	Height Adjuster, Right Rear	1101564
19	Guard, Rear **	671912
20	Screw **	26x245
21	Deflector, Chute	671929
22	Washer	017x37 Z
23	Bolt, Hex	01x121
24	Nut, NYLOCK	15x116
27	Bracket, Left Handle	1101303E700
28	Bracket, Right Handle	1101302E700
-	Warning, 20/22 OPEI '98	48x405
-	Cut Finger	48x6458
-	Warning, Install Chute	44x7329
-	Book, Instruction	F-0204___L

‡ Parts are available from an Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

** These parts are included when ordering Key number 1.

MODEL 202010X92A

REPAIR PARTS



KEY NO.	DESCRIPTION	PART NO.
1	Handle, Upper (Black)	1101555E701
2	Handle, Lower (Black)	672874E701
3	Bolt	002x77
4	Knob, Plastic	071294
7	Locknut	15x116
12	Guide, Rope	071530
13	Engine Stop Lever	671924E701
14	Bracket, Stop Lever	1101454
15	Fastener, Cable	1101353
16	Engine Stop Cable	1101136