



Ref #	Part Number	Qty	Description
1	951-10368		Fuel Tank
2	951-10369		Flywheel Shroud
3	951-10335		Rubber Fuel Tank Mounting Washer
4	951-10334		Oil Filler Tube Assembly
5	951-10333		Dipstick Assembly
6	951-10413		Cylinder Head Complete
7	951-10414		Short Block Assembly
8	951-10321		Stop Switch and Brake Assembly
9	951-10319		Recoil Spring and Pulley Assembly
10	951-10344		Push Rod Kit
11	951-10345		Valve Kit
12	951-10370		Oil Drain Plug and Washer Assembly
13	951-10366		Ignition Coil
14	951-10310		Carburetor Assembly
15	951-10307		Flywheel Key
16	951-10412		Air Cleaner Housing Assembly Complete
17	951-10342		Muffler Stud Assembly
18	951-10364		Fuel Line Kit - Inc. hoses, clamps & filter
19	951-10358		Fuel Filter
20	951-10300		Fuel Cap Assembly
21	951-10299		Recoil Starter Assembly
22	951-10298		Air Cleaner Kit
23	951-10297		Air Cleaner Thumb Screw
24	951-10411		Muffler Guard
25	951-10403		Muffler
26	951-10402		Muffler Gasket /Heat Shield
27	951-10387		Governor Return Spring
28	951-10292		Spark Plug
	952Z1P70FUA		Engine - Complete
	951-10326		Carburetor Kit - Major
	951-10323		Carburetor Kit - Minor
	951-10416		Gasket Kit - Complete
	951-10417		Gasket Kit - External
	951-10351		Spark Arrestor