




PORTABLE GENERATOR GÉNÉRATEUR PORTATIF GENERADOR PORTÁTIL

Model may vary slightly from
that shown

Model / Modèle / Modelo

PRO6500

01933



Illustrated Parts List

Questions? Help is just a
moment away!

Call: Generator Helpline -
1-800-743-4115 M-F 8-5 CT

Les Parties illustrées Enumèrent

Vous avez des questions?
Vous n'avez pas besoin d'aller loin
pour trouver de l'aide!

Appelez: Ligne d'assistance de
Générateur - 1-800-743-4115
M-F 8-5 CT

Las Partes ilustradas Listan


Preguntas? La ayuda es justa un
momento lejos!

Llamada: Generador Helpline -
1-800-743-4115 M-F 8-5 CT

BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

Manual No. 195994A
Revision J (09/06/2007)

EXPLODED VIEW - MAIN UNIT



Copyright © 2007 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

PARTS LIST - MAIN UNIT


Item	Part #	Description	Item	Part #	Description
1	B192958GS	KIT, Cradle (Includes Items 20, 31, 55, 76 & 77)	41	193272GS	VALVE, Fuel (Includes Item 99)
2	194218GS	MOUNT, Vibration	43	B1797GS	CLIP, Tree
3	B92531GS	SUPPORT, Engine	44	196035GS	ASSY, Fuel Tank, 7-Gal (Includes 41, 51, 52, 53 & 56)
4	190220GS	HOUSING, Engine Adapter	45	189135GS	CAP, Fuel
5	*	NUT, Hex, M8 - 1.25	48	195373GS	WIRE, Ground
6	NSP	ASSY, Alternator (see page 4)	51	194984GS	DECAL, Warning
7	B190723GS	SUPPORT, Eng/Muffler	52	94480GS	DECAL, Start Instructions
8	96796GS	WASHER, 8.4 x 22.2 x 3	53	192724GS	GAUGE, Fuel
9	194219GS	KIT, Vibration Mount	54	194448GS	KIT, Insulation w/ Clip
10	190274DGS	SBHCS, 3/8-16 x 7/8"	55	197797GS	DECAL, Fuel Shut-off
11	187365JGS	HHCS, 5/16-24 x 7.75	56	202997GS	DECAL, Warning CO
12	189160GS	NUT, 5/16-18 Serrated Flange	58	202531GS	ASSY, Control Panel
13	*	HHCS, 5/16-18 x 1-3/4"	60	J194389GS	SHIELD, Heat
14	92532GS	BRACKET, Muffler	76	195459GS	DECAL, Neutral Ground
15	710250	GASKET, Muffler	77	195940GS	DECAL, Ground French
16	*	HHCS, M6- 1.0 x 12	99	189759GS	KIT, Fuel Valve Repair
17	B4206GS	MUFFLER	900	§	ENGINE
18	67989GS	NUT, Flange Serrated			
19	83083GS	SCREEN, Spark Arrest			
20	B4986GS	DECAL, Ground			
21	194153GS	KIT, Vibration Mount			
22	86494GS	SCREW, M6-1.0 x 16 Wing			
24	J194390GS	SHIELD, Heat			
25	191190GS	CAP			
26	74908GS	TAPTITE, M5-0.8 x 10			
27	*	WASHER, 5/16 - M8, Lock			
28	*	HHCS, M8-1.25 x 25			
29	*	HHCS, 5/16-18 x 3/4			
31	200310GS	DECAL, Hot Muffler			
33	193157GS	HARNESS, Wire, Power			
34	195422GS	COVER, RBC, Plastic w/Cap			
35	791745	KIT, Fuel Line (cut to fit)			
36	*	WASHER, M6 - 1/4, Int, Shakeproof			
37	B2153GS	SCREW, 12-14 x 7/8 Self Drill			
38	192376GS	SCREW, 12-24 x 1/2 Thread Forming			
40	196034GS	KIT, Hardware Tank Fuel (Includes qty of 4)			

Parts Not Illustrated		
MS6669	MANUAL, Engine	
195994GS	MANUAL, Operator's	
43438GS	PLUG, 120/240V, 30A	
BB3061BGS	OIL BOTTLE	
202179GS	DECAL, Family EVP	
65787GS	CABLE, Battery Charge	
100523GS	PLUG, 125V, 30A	
193412GS	KIT, Decals	

* - Items without part numbers are common fasteners and are available at local hardware stores.


§ - Contact engine manufacturer.

EXPLODED VIEW AND PARTS LIST - ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	192919GS	ROTOR
3	192920AGS	STATOR
4	193336GS	RBC, (with O-Ring, p/n 189197GS)
5	86308HGS	HHCS, M6 - 1.0 x 140 SEMS
6	66386GS	ASSEMBLY, Holder, Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	WIRE-A, Ground
11	65791GS	BEARING
13	192403XGS	WIRE, Ground
14	189769GS	REGULATOR, Voltage, AVR
15	65795GS	RECTIFIER
16	66849AGS	TAPTITE, M5 - 0.8 x 20


EXPLODED VIEW AND PARTS LIST - CONTROL PANEL



Item	Part #	Description	Item	Part #	Description
1	B192833GS	PANEL, Control	19	193077GS	STRIP, Terminal
2	B192836GS	BOX, Control Panel	20	*	LOCKWASHER, M4
3	*	WASHER, Flat, #10 - M5	21	*	PPHMS, M5 - 0.8 x 20
4	*	LOCKWASHER, M5	22	*	NUT, M4 - 0.7
5	*	PPHMS, M5 - 0.8 x 12	23	*	WASHER, Flat, M4
6	*	WASHER, M6 - 1/4, Int. Shakeproof	24	192931GS	BRACKET, GFCI Breaker
7	82538GS	SWITCH, Rocker	25	*	WASHER, Shakeproof, Int. #8
8	90418GS	OUTLET, 12VDC, Snap	26	192828DGS	BREAKER, Circuit, GFCI, 30A
9	202602GS	HOUR METER	27	68868GS	OUTLET, 120V, 30A
10	*	LOCKWASHER, M3	28	43437GS	OUTLET, 120/240V, 30A
11	*	NUT, M3 - 0.5	29	68759GS	OUTLET, 120V, 20A, Duplex
12	*	PHMS, M3 - 0.5 x 10	30	193036GS	HARNESS, Wire
13	22694GS	HOUSING, Receptacle	31	193095GS	JUMPER, Terminal Block
14	87962GS	BREAKER, Circuit, 10A, 12V	32	202394GS	BREAKER, Circuit, 20A w/hardware
15	84028GS	TRANSFORMER, Idle Control			
16	64525GS	STANDOFF, Hex			
17	193362GS	PCB, Idle Control			
18	*	PHTS, #6-32 x 3/8			

* - Items without part numbers are common fasteners and are available at local hardware stores.

EXPLODED VIEW AND PARTS LIST - WHEEL KIT



Item	Part #	Description	Item	Part #	Description
1	*	WASHER, 5/8"	14	*	WASHER, Flat, 5/16 - M8
2	B4966GS	WHEEL	15	*	NUT, M8 Nylok
3	191267KGS	AXLE	16	*	WASHER, 1.2 x 0.346 x 0.03, Nylon
4	191265GS	E-RING	17		B4135GS PIN, with Lanyard
5	*	HHCS, M8 - 1.25 x 20 Lg.			
6	200543GS	ASSY, Support w/ Vibe Mounts			
9	67989GS	NUT, M8 Flange Serrated			
12	B193200GS	ASSY, Handle/Grip			
	198669GS	Grip			
13	*	HHCS, M8 - 1.25 x 45Lg			

Part Not Illustrated

200734GS SUBKIT, Hardware

* - Items without part numbers are common fasteners and are available at local hardware stores.