



## YK 1100 - 11 HP

| No. | P/N     | Description                  | No. | P/N   | Description               | No. | P/N     | Description               |
|-----|---------|------------------------------|-----|-------|---------------------------|-----|---------|---------------------------|
| 1   | 31-03 M | Recoil Starter Assy (Maroon) | 17  | 36-61 | Piston Ring               | 34  | 36-72   | Valve Spring              |
| 1   | 31-03 B | Recoil Starter Assy (Black)  | 18  | 36-34 | Piston Assy.              | 35  | 01-03   | Head Cover Comp.          |
| 2   |         | Recoil Starter Cup           | 19  | 36-17 | Cam Shaft Assy.           | 36  | 99-13   | Cylinder Head Assy.       |
| 3   | 01-35   | Cooling Fan                  | 20  | 36-89 | Valve Lifter Assy         | 37  | 49-14   | Carburetor Assy.          |
| 4   | 01-54   | Fly Wheel                    | 21  | 36-85 | Push Rod                  | 38  | 49-159  | Air Cleaner/Spacer Gasket |
| 5   | 49-45   | Oil Seal                     | 22  | 01-31 | Control Assy.             | 39  | 49-149  | Carburetor Gasket         |
| 6   | 36-50   | Cylinder Barrel              | 23  | 50-08 | Head Gasket               | 40  | 33-06   | Ignition Coil Assy        |
| 7   | 33-12   | Engine Stop Switch Assy      | 24  | 36-68 | Valve Assembly In/Exhaust | 41  | 30-06   | Air Cleaner Element       |
| 8   | 33-20   | Oil Level Switch Assy.       | 25  | 07-50 | Fuel Tank Joint.          | 42  | 30-03   | Air Cleaner Assembly      |
| 9   | 36-95   | Governor Gear Assy.          | 26  | 33-11 | Spark Plug                | 43  | 01-34 M | Fan Cover Comp. (Maroon)  |
| 10  | 36-08 Q | Crankshaft Assy.             | 27  | 35-10 | Muffler Comp.             | 43  | 01-34 B | Fan Cover Comp. (Black)   |
| 11  | 50-43   | Oil Pan Gasket               | 28  | 35-11 | Muffler Protector         | 44  | 35-19   | Spark Arrester            |
| 12  | 36-119  | Crankcase and Oil Pan Assy.  | 29  | 07-10 | Fuel Filter & Holder      | 45  | 35-47   | Muffler Gasket            |
| 13  | 07-16   | Oil Dip Stick                | 30  | 07-11 | Fuel Tank Cap             | 46  | 35-49   | Ex. Pipe Gasket           |
| 14  | 49-45   | Oil Seal                     | 31  | 07-08 | Fuel Tank Assy.           | 47  | 36-78   | Balancer Weight Assy.     |
| 15  | 45-04   | Bearing                      | 32  | 35-14 | Exhaust Pipe Comp.        |     |         |                           |
| 16  | 36-26   | Connecting Rod               | 33  | 36-74 | Rocker Arm Assy.          |     |         |                           |

### Accessory Parts

| No. | P/N    | Description                            | No. | P/N   | Description                  | No. | P/N   | Description                          |
|-----|--------|--|-----|-------|------------------------------|-----|-------|--------------------------------------|
|     | 04-02  | Recoil Starter Flange Bolt             |     | 33-49 | Electric Starter Motor Assy. |     | 49-70 | Generator Carb. Assy.                |
|     | 30-107 | Air Cleaner Grommet                    |     | 35-05 | Muffler Assy                 |     | 49-70 | Generator Carb. Assy. Electric Start |
|     | 30-115 | Air Cleaner Wing Nut                   |     | 49-04 | Carburetor Repair Kit        |     | 49-86 | Carb. Choke Lever Comp.              |
|     | 33-15  | Noise Suppressor Cap / Spark Plug Boot |     | 49-20 | Carb. Float Chamber Set      |     | 99-06 | Cylinder Barrel Assy.                |
|     | 33-22  | Oil Alert Unit                         |     | 49-23 | Carburetor Float Set         |     |       |                                      |